

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



MUTE
/ MENU
/ EXIT
1/2/3/4/5
6/7/8/9/0
/ INPUT
CH / LIST
PLAYLIST
GOTO
/ 16:9/4:3
TV / TXT
VOL+
VOL -
+
-
UP
DOWN
LEFT
RIGHT
OK
ECO / ENERGY
/ SOUND
INFO

EPG
FAV
PICTURE
HOLD
RED
GREEN
YELLOW
BLUE / ☺ / SLEEP
/ AUDIO
SIZE
SUBPABE
/ SUBTITLE
SKIP NEXT
SKIP PREV
/ REPEAT
PAUSE / TIMESHIFT
STOP
REC
REW
PLAY
FWD

POWER, MUTE, / MENU, MENU, / EXIT, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / INPUT, / SOURCE, CH / LIST, PLAYLIST, GOTO, / 169/43, TV / TXT, VOL+, VOL, ABAJO, IZQUIERDA, DERECHA, BACK, ECO / ENERGY, SLEEP, / SOUND, TV/DTV, INFO, EPG, FAV, PICTURE, / NET TV, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL / / SLEEP, AZUL, / AUDIO, SIZE, SUBPABE, / SUBTITLE, SKIP NEXT, SKIP PREV, / REPEAT, PAUSE / TIMESHIFT, STOP, REC, REW, PLAY, FWD, .