

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



SYSTEM POWER
MUTE
MENU
EXIT
1 / STEREO
2 / HALL 1
3 / HALL 2
4 / CHURCH
5 / JAZZ
6 / ROCK
7 / MUSIC
8 / ENTERTAIN
9 / MOVE
0 / THX
+100 / NIGHT
+10 / DOLBY/DTS
ON SCREEN
STRAIGHT EFFECT
EX/ES
VOLUME+
VOLUME -
UP
DOWN
LEFT
RIGHT

ENTER
SLEEP
SPEAKERS A
SPEAKERS B
STANDBY
CABLE
CD
CD - R
DTV/LD
DVD
DVR
MD/TAPE
MULTI CH IN
PHONO
SAT
TUNER
V - AUX
VCR 1
VCR 2

SYSTEM POWER, POWER, MUTE, MENU, EXIT, 1 / STEREO, 2 / HALL 1, 3 / HALL 2, 4 / CHURCH, 5 / JAZZ, 6 / ROCK, 7 / MUSIC, 8 / ENTERTAIN, 9 / MOVE, 0 / THX, 0+100 / NIGHT, / SOURCE, +10 / DOLBY/DTS, ON SCREEN, STRAIGHT EFFECT, EX/ES, VOLUME+, VOL+, VOLUME, VOL, ABAJO, IZQUIERDA, DERECHA, ENTER, SLEEP, SPEAKERS A, VERDE, SPEAKERS B, AZUL, STANDBY, CABLE, DTV/LD, DVD, DVR, MD/TAPE, MULTI CH IN, PHONO, SAT, 0TUNER, AUX, VCR 1, VCR 2, .