

# **FUNCIONES DEL MANDO PROGRAMADO:**

En este documento puede visualizar las funciones que se van a programar en el mando.  
 El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.  
 Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
OPTION
ECO
CBL/SAT
DVD
BLU -- RAY
GAME
AUX
MEDIA PLAYER
USB
TV AUDIO
TUNER
BLUETOOTH
INTERNET RADIO
SETUP
VOLUME+
VOLUME -
SKIP NEXT/TUNE+
SKIP PREV/TUNE -
UP
DOWN
LEFT
RIGHT

ENTER
BACK
SLEEP
INFO
PLAY/PAUSE
QUICK SELECT 1
QUICK SELECT 2
QUICK SELECT 3
QUICK SELECT 4
CH/PAGE+
CH/PAGE -
RED/MUSIC
GREEN/MOVIE
YELLOW/PURE
BLUE/GAME

POWER, MUTE, OPTION, MENU, ECO, EXIT, CBL/SAT, DVD, BLU, RAY, GAME, AUX, MEDIA PLAYER, USB, TV AUDIO, TUNER, 0AZULTOOTH, / SOURCE, INTERNET RADIO, SETARRIBA, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT/TUNE+, SKIP PREV/TUNE, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, SLEEP, INFO, PLAY/PAUSE, AMARILLO, QUICK SELECT 1, QUICK SELECT 2, QUICK SELECT 3, QUICK SELECT 4, CH/PAGE+, CH/PAGE, ROJO/MUSIC, ROJO, VERDE/MOVIE, VERDE, AMARILLO/PURE, AZUL/GAME, AZUL, .