

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
OPTION
ECO
AUX 1
AUX 2
BLUETOOTH
BLUE RAY
CBL/SAT
CD
GAME
INTERNET RADIO
MEDIA PLAYER
PHONO
TUNER
TV AUDIO
SETUP
VOLUME+
VOLUME -
SKIP NEXT/TUNE+
SKIP PREV/TUNE -
UP
DOWN
LEFT
RIGHT

ENTER
BACK
SLEEP
USB
STOP
PLAY/PAUSE
QUICK SELECT 1
QUICK SELECT 2
QUICK SELECT 3
QUICK SELECT 4
CH/PAGE+
CH/PAGE -
MUSIC
MOVIE
PURE
GAME

POWER, MUTE, OPTION, MENU, ECO, EXIT, AUX 1, AUX 2, AZULTOOTH, AZUL RAY, CBL/SAT, GAME, INTERNET RADIO, MEDIA PLAYER, PHONO, OTUNER, / SOURCE, TV AUDIO, SETARRIBA, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT/TUNE+, SKIP PREV/TUNE, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, SLEEP, USB, TV/DTV, STOP, / SMART, PLAY/PAUSE, AMARILLO, QUICK SELECT 1, QUICK SELECT 2, QUICK SELECT 3, QUICK SELECT 4, CH/PAGE+, CH/PAGE, MUSIC, ROJO, MOVIE, VERDE, PURE, AZUL, .