

## **FUNCIONES DEL MANDO PROGRAMADO:**

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
DISC MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
INPUT
HDMI
DISPLAY
NOT USED
INSTANT SKIP
SUBTITLE
NOT USED
NOT USED
CH+
CH-
UP
DOWN
LEFT
RIGHT
OK
RETURN
TIME SLEEP
SAT LINK
INFO

GUIDE
DUBBING
EJECT
PAUSE
STOP
REC
REW
PLAY
FWD
TOP MENU
VCR
DVD
TIMER SET
TIMER PROG
1,3/0.8 PLAY
SETUP
TEXT
SKIP NEXT CHAP
SKIP PREV CHAP
REC MODE
RED
GREEN
YELLOW
BLUE

POWER, MUTE, DISC, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, INPUT, HDMI, DISPLAY, NOT USED, INSTANT SKIP, SUBTITLE, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, RETURN, BACK, TIME SLEEP, SLEEP, SAT LINK, TV/DTV, INFO, GUIDE, EPG, DUBBING, FAV, EJECT, PAUSE, STOP, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, TOP, VCR, DVD, TIMER SET, TIMER PROG, 13/08, SETARRIBA, TEXT, SKIP NEXT CHAP, SKIP PREV CHAP, REC MODE, .