

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
-/--
PICTURE
SIZE / PROG.
SUBT. / SUBTITLE
TV/TXT / SETUP
VOL+
VOL-
CH+
CH-
UP
DOWN
LEFT
RIGHT
OK
SCREEN
TV/RADIO / GO TO
INFO

EPG / TITLE
FAV / DVD MENU
HOLD
RED / ZOOM
GREEN / SLOW
YELLOW / REP.
BLUE / A-B / TIME
AUDIO / LANG.
SOUND
ANG. / SUBPAGE
SKIP PREV.
SKIP NEXT
INDEX
PAUSE
STOP
REC / EJECT
REW
PLAY
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 0/6/7/8/9/, 0/INPUT, / AV, PICTURE, SIZE / PROG, SUBT / SUBTITLE, TV/TXT / SETARRIBA, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK, SCREEN, SLEEP, TV/RADIO / GO, TV/DTV, INFO, EPG / TITLE, EPG, FAV / DVD MENU, FAV, HOLD, ROJO / ZOOM, ROJO, VERDE / SLOW, VERDE, AMARILLO / REP, AMARILLO, AZUL / A, B / TIME, AZUL, AUDIO / LANG, SOUND, ANG / SUBPAGE, SKIP, PREV, SKIP NEXT, INDEX, PAUSE, STOP, REC / EJECT, REW, PLAY, FWD, .