

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
DELETE
MEDIA
AUTO
MIX
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK / ENTER
SLEEP
DT / RADIO
INFO

EPG
FAV
ASPECT
STILL
HOLD
RED
GREEN
YELLOW
BLUE
AUDIO
REVEAL
SIZE
FILE
SUBTITLE
SKIP NEXT
SKIP PREV
ZOOM +/-
INDEX
P. MODE
S. MODE
STOP
REC
REW
PLAY / PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, DELETE, MEDIA, AUTO, MIX, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, OK / ENTER, BACK, SLEEP, DT / RADIO, TV/DTV, INFO, EPG, FAV, ASPECT, / NET TV, STILL, HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, REVEAL, SIZE, FILE, SUBTITLE, SKIP NEXT, SKIP PREV, ZOOM +/, ARRIBA/ABAJO, INDEX, P MODE, S MODE, STOP, REC, REW, PLAY / PAUSE, FWD, .