

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



1/2/3/4/5
6/7/8/9/0
SOURCE
EDIT
DISPLAY
ZOOM
TEXT
SEL. / FAVOR./VOL +
LOAD / FAVOR./VOL -
CH+
CH-
UP
DOWN
LEFT
RIGHT
ENTER
TIME SHIFT
DTV
DIMMER
EPG
RED

GREEN
YELLOW
BLUE
AUDIO
HDD
LAN
TV HMR
USB
SUBTITLE
SKIP ←
SKIP →
SKIP PREV.
SKIP NEXT
A-B
TIMER REC
TV SYSTEM
EJECT / GO TO
PAUSE
STOP
REC
REW
PLAY
FWD

POWER, MUTE, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, EDIT, DISPLAY, ZOOM, TEXT, SEL / FAVOR/VOL +, VOL+, LOAD / FAVOR/VOL, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, TIME, SHIFT, SLEEP, DTV, TV/DTV, DIMMER, INFO, EPG, ROJO, VERDE, AMARILLO, AZUL, AUDIO, HDD, LAN, TV HMR, USB, SUBTITLE, SKIP, SKIP, SKIP PREV, SKIP NEXT, TIMER REC, TV SYSTEM, TV/DTV, EJECT / GO TO, PAUSE, STOP, REC, REW, PLAY, FWD, .