

## **FUNCIONES DEL MANDO PROGRAMADO:**

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



STAND BY	OPEN / CLOSE
AUDIO	STOP
MENU	RECORD
CLEAR	SEARCH REW
1/2/3/4/5	PLAY / PAUSE
6/7/8/9/0	SEARCH FWD
VIDEO SOURCE	INSERT CHAPTER
+10	SETUP
DISPLAY	PROGRAM-
ZOOM	PROGRAM+
ANGLE	REPEAT
SUBTITLE	A-B
SKIP NEXT	REC. MODE
SKIP PREV.	
UP	
DOWN	
LEFT	
RIGHT	
SELECT	
RETURN	
TIMER	
TV / DVD	
TITLE	
SEARCH MODE	
PLAY MODE	

STAND BY, POWER, AUDIO, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0VIDEO SOURCE, DISPLAY, ZOOM, ANGLE, SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, SELECT, RETURN, BACK, TIMER, SLEEP, TV / DVD, TV/DTV, TITLE, INFO, SEARCH MODE, EPG, PLAY MODE, FAV, OPEN / CLOSE, STOP, RECORD, ROJO, SEARCH REW, VERDE, PLAY, / PAUSE, AMARILLO, SEARCH, FWD, AZUL, INSERT CHAPTER, SETARRIBA, PROGRAM, PROGRAM+, REPEAT, REC, MODE, .