

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER RECEIVER
MUTE
AV 1/2/3/4/5
HDMI 1/2/3/4
AUDIO 1/2
DOCK
AM
FM
TUNER
V – AUX
VOLUME+
VOLUME -
TUNING+
TUNING -
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
INFO
MEMORY
OPTION
SCENE – BD/DVD

SCENE – CD
SCENE – RADIO
SCENE – TV
MOVIE
MUSIC
STEREO / ENHANCER
STRAIGHT
SUR. DECODE
PRESET PREV
PRESET NEXT
SETUP
iPod
MENU
DOWN
UP
LEFT
RIGHT
ENTER
SKIP NEXT/PREV
PAUSE
STOP
REW
PLAY
FWD

POWER RECEIVER, POWER, MUTE, AV 1/2/3/4/5, 1/2/3/4/5, HDMI 1/2/3/4, 6/7/8/9, AUDIO 1/2, AV/, 0DOCK, TUNER, AUX, VOLUME+, VOL+, VOLUME, VOL, TUNING+, TUNING, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, INFO, MEMORY, EPG, OPTION, FAV, SCENE, BD/DVD, ROJO, VERDE, RADIO, AMARILLO, AZUL, MOVIE, MUSIC, STEREO / ENHANCER, STRAIGHT, SUR DECODE, PRESET, PREV, SHIFT, PRESET, NEXT, SETARRIBA, IPOD, MENU, SKIP, NEXT/PREV, P+/, PAUSE, STOP, REW, PLAY, FWD, .