

# FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.  
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.  
Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
1/2/3/4/5
6/7/8/9/0
AUDIO SEL.
DISPLAY
LEVEL
VOLUME+
VOLUME-
PRESET/CH +
PRESET/CH -
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
SCENE 1
SCENE 2
SCENE 3
SCENE 4
STANDBY
CD

DTV / CBL.
DVD
DVR
MD / CDR
MULTI-CH. IN
PHONO
TUNER
V-AUX / DOCK
VCR
XM
ENT.
CLASSICAL
ENHANCER
ENTERTAIN
LIVE / CLUB
MOVIE
NIGHT
PURE DIRECT
STEREO
STRAIGHT
SUR. DECODE

POWER, MUTE, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AUDIO SEL, DISPLAY, LEVEL, VOLUME+, VOL+, VOLUME, VOL, PRESET/CH +, PRESET/CH, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, SCENE 1, ROJO, SCENE 2, VERDE, SCENE 3, AMARILLO, SCENE 4, AZUL, STANDBY, DTV / CBL, DVD, DVR, MD / CDR, MULTI, CH IN, PHONO, TUNER, AUX / DOCK, VCR, 0XM, ENT, CLASSICAL, INFO, ENHANCER, EPG, ENTERTAIN, FAV, LIVE / CLUB, MOVIE, NIGHT, PURE DIRECT, STEREO, STRAIGHT, SUR DECODE, .