

# FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



POWER
MUTE
MENU
RECALL
1/2/3/5/7/9
4 / ZOOM
6 / ROTATE
8 / OPTION
0 / SLIDE
AV
CH. LIST
DISPLAY
WIDE
e
TELETEXT
VOL -/+
CH/PG. -/+
UP
DOWN
LEFT
RIGHT
OK
BACK
SLEEP
TV

EPG
SRS / BBE
HOLD
RED / -
GREEN /
YELLOW /
BLUE /
MPX
PIP / PBP / POP
SWAP
ACTIVE
POSITION
SIZE / MODE
PC
SCART
SIZE
SUBTITLE
SKIP PREV./NEXT
↺
ENTER
↻
CARD / MGW
STOP
REW / FWD
PLAY

POWER, MUTE, MENU, RECALL, EXIT, 1/2/3/5/7/9, 4 / ZOOM, 6 / ROTATE, 8 / OPTION, 0 / SLIDE, 0AV, CH LIST, DISPLAY, WIDE, TELETEXT, VOL, CH/PG, ABAJO, IZQUIERDA, DERECHA, BACK, SLEEP, TV/DTV, EPG, SRS / BBE, FAV, HOLD, ROJO / ROJO, VERDE /, VERDE, AMARILLO /, AMARILLO, AZUL /, AZUL, MPX, PIP / PBP / POP, SWAP, ACTIVE, POSITION, SIZE / MODE, SCART, SIZE, SUBTITLE, SKIP PREV/NEXT, ENTER, CARD / MGW, TV/DTV, STOP, REW / FWD, VERDE/AZUL, PLAY, .