

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER	PAUSE
MUTE	STOP
DIALOG ENHANCE MENU	GREEN
FM	PLAY
AM	FWD
DVD	SKIP NEXT CHAP
DVR	SKIP PREV CHAP
CD	SETUP
CD-R	EFFECT CH. SELECT
DVD 5.1	LEVEL +
USB	LEVEL -
ATTENUATION	
MIDNIGHT LOUDNESS	
VOL+ / VOL-	
INPUT NEXT	
UP/DOWN/LEFT/RIGH T/OK	
DIMMER	
TUNER EDIT	
SURR STANDARD	
SURR ADVANCED	
STEREO	
ACOUSTIC EQ	
S. RETREIVER	
SYNTH CH+ /CH-	
CLASS	



POWER, MUTE, DIALOG ENHANCE, MENU, DVD, DVR, DVD 5.1, USB, ATTENUATION, MIDNIGHT LOUDNESS, VOL+ / VOL-, VOL+ / VOL-, INPUT NEXT, ARRIBA/ABAJO/IZQUIERDA/RIGH, T/OK, DIMMER, TUNER EDIT, SURR STANDARD, SURR ADVANCED, STEREO, ACOUSTIC EQ, EPG, S RETREIVER, INFO, SYNTH, CH+ /CH-, CLASS, FAV, PAUSE, STOP, VERDE, PLAY, AMARILLO, FWD, AZUL, SKIP NEXT CHAP, SKIP, PREV CHAP, SETARRIBA, EFFECT CH, SELECT, LEVEL +, LEVEL, ABAJO, .