

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



MUTE
HOME
TOP MENU
FM/AM
USB
BLUETOOTH
DISPLAY
STRAIGHT
SETUP
ENHANCER
VOLUME +
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
SLEEP
BASS
PUP – UP/MENU
OPTION

PAUSE
STOP
REW / TUNING -
PLAY / MEMORY
FWD / TUNING+
SCENE BD/DVD
SCENE TV
SCENE NET
SCENE RADIO
PRESET+
PRESET -
INPUT+
INPUT -
PROGRAM -
PROGRAM+
RED
GREEN
YELLOW
BLUE

POWER, MUTE, HOME, MENU, TOP MENU, EXIT, FM/AM, USB, AZULTOOTH, DISPLAY, STRAIGHT, SETARRIBA, ENHANCER, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, BASS, TV/DTV, PARRIBA, ARRIBA/MENU, INFO, OPTION, EPG, PAUSE, STOP, / SMART, REW / TUNING, VERDE, PLAY / MEMORY, AMARILLO, FWD / TUNING+, AZUL, SCENE BD/DVD, SCENE TV, SHFIT+, SCENE NET, SCENE RADIO, PRESET+, PRESET, INPUT+, INPUT, PROGRAM, PROGRAM+, ROJO, .