

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
 El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
 Revise que localiza todas las funciones que necesita antes de realizar la compra.



⏻ /
DVD MENU
CANCEL
1/2/3/4/5
6/7/8/9/0
DVD
VCR
DISPLAY
ZOOM
SETUP MENU
SUBTITLE
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
OK
RETURN
SLOW
TV / VCR
TITLE
MEMORY
PLAY MODE
OPEN/CLOSE

PAUSE
STOP
REW
PLAY
FWD
SKIP SEARCH
ZERO RETURN
ANGLE
PROG. 1
🕒 / PROG. 4
REPEAT A - B
OSD
A. MONITOR

POWER, DVD MENU, MENU, CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DVD, SOURCE, VCR, DISPLAY, ZOOM, SETARRIBA MENU, SUBTITLE, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, RETURN, BACK, SLOW, SLEEP, TV / VCR, TV/DTV, TITLE, INFO, MEMORY, EPG, PLAY MODE, FAV, OPEN/CLOSE, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, SKIP SEARCH, ZERO RETURN, 0ANGLE, PROG 1, / PROG 4, REPEAT, OSD, A MONITOR, .