

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



⏻ / VHS
AUDIO
MENU / PLAY LIST
CANCEL / RESET
1/2/3/4/5
6/7/8/9/0
VHS
-/--
VHS STATUS
CINEMA MODE
OFF TIMER
EXT LINK
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN / EXIT
⌚ / TIMER
INPUT
DVD RAM / DUBBING
PLAY MODE
PROG. / CHECK

REC MODE
PAUSE / STEP
STOP
REC
REW
PLAY
FWD
SETUP
CH+
CH -
REPEAT
I - TIMER
TV COI
⏻
AV
VOLUME+
VOLUME -
CH+
CH-

/ VHS, POWER, AUDIO, MUTE, MENU / PLAY LIST, MENU, CANCEL / RESET, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0VHS, SOURCE, VHS STATUS, CINEMA MODE, OFF TIMER, EXT LINK, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN / EXIT, BACK, / TIMER, SLEEP, INPUT, TV/DTV, DVD RAM / DUBBING, INFO, PLAY MODE, EPG, PROG / CHECK, FAV, REC MODE, / NET TV, PAUSE / STEP, STOP, / SMART, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, SETARRIBA, CH+, REPEAT, TIMER, TV CONTROL, SHIFT, VOLUME+, VOL+, VOLUME, VOL, .