

FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



STANDBY
MUTE
SETUP
1/2/3/4/5
6/7/8/9/0
SOURCE
GO TO
PROGRAM
ZOOM
SUBTITLE
TTX / TITLE
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
RETURN / EXIT
TV / RADIO
INFO
EPG
FAVORITE

SLOW
RED / REPEAT
GREEN / A - B
YELLOW / MENU
BLUE / ANGLE
AUDIO
VCR
SKIP NEXT
SKIP PREV
OPEN / CLOSE
STOP
REW
PLAY / PAUSE
FWD

STANDBY, POWER, MUTE, SETARRIBA, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, PROGRAM, ZOOM, SUBTITLE, TTX, / TITLE, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, RETURN / EXIT, BACK, TV / RADIO, TV/DTV, INFO, EPG, FAVORITE, FAV, SLOW, ROJO / REPEAT, ROJO, VERDE / A, VERDE, AMARILLO / MENU, AMARILLO, AZUL / ANGLE, AZUL, AUDIO, VCR, SKIP NEXT, SKIP PREV, OPEN, / CLOSE, STOP, REW, PLAY / PAUSE, FWD, .