

# FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.

El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.

Revise que localiza todas las funciones que necesita antes de realizar la compra.



STANDBY
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
REC. LIST
DISPLAY
SIZE
SUBPAGE
TEXT
VOL+
VOL-
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK / ENTER
SLEEP
TV / RADIO
INDEX

EPG
FAVORITE
STOP
RED
GREEN
YELLOW
BLUE
AUDIO
P. MODE
S. MODE
REVEAL
SUBTITLE
SKIP NEXT
SKIP PREV
MEDIA
STOP
REC
REW
PLAY/PAUSE - TIME SHIFT
FWD

STANDBY, POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, SOURCE, REC LIST, DISPLAY, SIZE, SUBPAGE, TEXT, VOL+, VOL, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, OK / ENTER, BACK, SLEEP, TV / RADIO, TV/DTV, INDEX, INFO, EPG, FAVORITE, FAV, STOP, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, P MODE, S MODE, REVEAL, SUBTITLE, SKIP, NEXT, PREV, MEDIA, REC, REW, PLAY/PAUSE, TIME SHIFT, FWD, .