FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY / ON
AUDIO
/ HOME MENU
EXIT
1/2/3/4/5
6/7/8/9/0
HDMI
/ SKIP SEARCH
DISPLAY
CONTINUED
MENU / POP UP MENU
SUBTITLE
SKIP NEX
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
/ REPLAY
CD / SACD
FL DIMMER
HOME MEDIA GALLERY
TOP MENU

OPEN / CLOSE
PAUSE
STOP
REW
PLAY
FWD
2 nd AUDIO
CLEAR
2 nd VIDEO
ANGLE
REPEAT
A – B
RED / PROGRAM
GREEN / BOOKMARK
YELLOW / ZOOM
BLUE / INDEX

STANDBY / ON, POWER, AUDIO, MUTE, / HOME MENU, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0HDMI, / SOURCE, / SKIP SEARCH, DISPLAY, CONTINUED, MENU / POP ARRIBA MENU, SUBTITLE, SKIP NEX, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, / REPLAY, SLEEP, CD / SACD, TV/DTV, FL DIMMER, INFO, HOME MEDIA GALLERY, EPG, TOP MENU, FAV, OPEN / CLOSE, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, CLEAR, VIDEO, ANGLE, REPEAT, ROJO / PROGRAM, ROJO, VERDE / BOOKMARK, AMARILLO / ZOOM, AZUL / INDEX, .