FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
AUDIO
/ / HOME
/ / EXIT
1/2/3/4/5
6/7/8/9/0
/ CH LIST
FULL SCREEN
PIP
TTX / MIX
/ PROG+
/ PROG -
UP
DOWN
LEFT
RIGHT
↵
/ / RETURN
/ INFO
/ GUIDE
SOCIAL TV
REC PAUSE
WWW
RED / A
GREEN / B

YELLOW / C / PIP CH -
BLUE / D / PIP CH+
AD / SUBTITLE
SKIP NEXT
SKIP PREV
PAUSE
STOP
REC
REW
PLAY
FWD

POWER, AUDIO, MUTE, / / HOME, MENU, / / EXIT, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0 / CH LIST, FULL SCREEN, PIP, TTX / MIX, / PROG+, / PROG, ABAJO, IZQUIERDA, DERECHA, / / RETURN, BACK, / INFO, INFO, / GUIDE, EPG, SOCIAL TV, / NET TV, REC PAUSE, WWW, / SMART, ROJO / A, ROJO, VERDE / B, VERDE, AMARILLO / C / PIP CH, AMARILLO, AZUL / D / PIP CH+, AZUL, AD / SUBTITLE, SKIP NEXT, SKIP PREV, PAUSE, STOP, REC, REW, PLAY, FWD, .