FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
/ AUDIO
/ HOME
CLEAR
1/2/3/4/5
6/7/8/9/0
AV / INPUT
MENU / LIST
DISPLAY
ZOOM
THUMBNAIL
/ SUBTITLE
SKIP NEXT
SKIP PREV
UP / PR/CH+
DOWN / PR/CH -
LEFT
RIGHT
OK
/ RETURN
I.SKIP
TV / DVD
TITLE
CH. ADD
MARKER

OPEN / CLOSE
PAUSE / STEP
STOP
REC
REW
PLAY
FWD
SEARCH
REC MODE
PLAY MODE

POWER, / AUDIO, MUTE, / HOME, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0AV / INPUT, / SOURCE, MENU / LIST, DISPLAY, ZOOM, THUMBNAIL, / SUBTITLE, SKIP NEXT, SKIP PREV, ARRIBA / PR/CH+, ABAJO / PR/CH, ABAJO, IZQUIERDA, DERECHA, / RETURN, BACK, ISKIP, SLEEP, TV / DVD, TV/DTV, TITLE, INFO, CH ADD, EPG, MARKER, FAV, OPEN / CLOSE, / NET TV, PAUSE / STEP, STOP, / SMART, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, SEARCH, REC MODE, PLAY MODE, .