FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

| ON
MUTE
CD SYNC.
DISC SKIP
1/2/3/4/5
6/7/8/9/0
TEST
VOLUME+
VOLUME -
CS SKIP NEXT
CD SKIP PREV
REAR+
REAR -
CENTER -
CENTER+
CENTER MODE
SURROUND ON/OFF
SLEEP
BAND
SURROUND DELAY
SURROUND MODE
DIRECT
CD PAUSE
CD STOP
CD PLAY/PAUSE

STANDBY
AV – 3
AV – 2
AV – 1
TUNER
PHONO
CD
P.CALL+
P.CALL -
TUNING+
TUNING -
TAPE I
TAPE II
TAPE M.
TAPE REV. PLAY
TAPE STOP
TAPE REC
TAPE PLAY

POWER, MUTE, CD SYNC, MENU, DISC SKIP, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0TEST, VOLUME+, VOL+, VOLUME, VOL, CS SKIP NEXT, CD SKIP PREV, REAR+, REAR, ABAJO, CENTER, IZQUIERDA, CENTER+, DERECHA, CENTER MODE, SURROUND ON/OFF, BACK, SLEEP, BAND, TV/DTV, SURROUND DELAY, INFO, SURROUND MODE, EPG, DIRECT, FAV, CD PAUSE, CD STOP, / SMART, CD PLAY/PAUSE, AMARILLO, STANDBY, TUNER, PHONO, PCALL+, VOL+, PCALL, VOL, TUNING+, TUNING, TAPE I, TAPE II, TAPE M, TAPE REV PLAY, TAPE STOP, TAPE REC, ROJO, TAPE PLAY, .