FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON/STANDBY
MUTE
OPTION
1/2/3/4/5
6/7/8/9/0
+10
SETUP
VOLUME+
VOLUME -
CH/PAGE+
CH/PAGE -
UP
DOWN
LEFT
RIGHT
ENTER
BACK
SLEEP
AUX 1
AUX 2
BLURAY
CBL/SAT
CD
DVD
GAME

INTERNET RADIO
IPOD/USB
MEDIA PLAYER
M – XP
NETWORK
PHONO
TUNER
FAVORITE STATION 1
FAVORITE STATION 2
FAVORITE STATION 3
FAVORITE STATION 4
SOUND MODE MOVIE
SOUND MODE MUSIC
SOUND MODE PURE
SOUND MODE GAME

ON/STANDBY, POWER, MUTE, OPTION, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0+1, SETARRIBA, VOLUME+, VOL+, VOLUME, VOL, CH/PAGE+, CH/PAGE, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, SLEEP, AUX 1, AUX 2, BLURAY, CBL/SAT, DVD, GAME, INTERNET RADIO, IPOD/USB, MEDIA PLAYER, NETWORK, PHONO, TUNER, FAVORITE STATION 1, FAVORITE STATION 2, FAVORITE STATION 3, FAVORITE STATION 4, SOUND MODE MOVIE, ROJO, SOUND MODE MUSIC, VERDE, SOUND MODE PURE, AMARILLO, SOUND MODE GAME, AZUL, .