FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
HOME
VIDEO OUT
1/2/3/4/5
6/7/8/9/0
DEVICE
4:3 / 16:9
BACKLIGHT LCD
GOTO
SETUP
SUBTITLE
VOL+
VOL -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT / PROG -
RIGHT / PROG+
ENTER
↩
SLIDE SHOW
SELECT/BGM
INFO

FILE
PHOTO DIGEST
STOP
REW
PLAY/PAUSE
FWD
AUDIO
MUSIC
COPY
PHOTO
ZOOM
A – B ROTATE
← ☐ →
REPEAT
MOVIE

POWER, MUTE, HOME, MENU, VIDEO OUT, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DEVICE, / SOURCE, 43 / 169, BACKLIGHT LCD, GOTO, SETARRIBA, SUBTITLE, VOL+, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA / PROG, IZQUIERDA, DERECHA / PROG+, DERECHA, ENTER, BACK, SLIDE SHOW, SLEEP, SELECT/BGM, TV/DTV, INFO, FILE, EPG, PHOTO DIGEST, FAV, STOP, / SMART, REW, VERDE, PLAY/PAUSE, AMARILLO, FWD, AZUL, AUDIO, MUSIC, COPY, PHOTO, ZOOM, B ROTATE, SHFIT+, REPEAT, MOVIE, .