FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
INPUT
DISPLAY
ASPECT
SOUND
TV/TXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
RECALL
SLEEP
TUNER
EPG
FAV

PICTURE
FREEZE
RED / TITLE
GREEN / GOTO
YELLOW / REPEAT
BLUE / A – B
NICAM/A2
CANCEL
REVEAL
SUBTITLE
SKIP NEXT
SKIP PREV
R.LIST
STOP
REC
REW
PLAY/PAUSE
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, / SOURCE, DISPLAY, ASPECT, SOUND, TV/TXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, RECALL, BACK, SLEEP, TUNER, TV/DTV, EPG, FAV, PICTURE, / NET TV, FREEZE, / SMART, ROJO / TITLE, ROJO, VERDE / GOTO, VERDE, AMARILLO / REPEAT, AMARILLO, AZUL / A, AZUL, NICAM/A2, CANCEL, REVEAL, SUBTITLE, SKIP NEXT, SKIP PREV, RLIST, STOP, REC, REW, PLAY/PAUSE, FWD, .