FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY/ON
MUTE
MENU / CO / CLEAR
CLOCK / CALL
1/2/3/4/5
6/7/8/9/0
+10
DISPLAY
S.BASS
VOLUME+
VOLUME -
PRESET/SKIP NEXT
PRESET/SKIP PREV
INPUT+
INPUT -
ENTER
REPEAT
SLEEP
TUNER/BAND
TONE
FOLDER
SHUFFLE YES/MODE
CD PAUSE
CD STOP
REW / TUN -

CD PLAY
FWD / TUN+
TIMER
DOCK STOP
DOCK PAUSE
DOCK PLAY
USB STOP
USB PLAY
USB PAUSE
MD/TAPE PAUSE
MD/TAPE STOP
MD/TAPE PLAY

STANDBY/ON, POWER, MUTE, MENU / CO / CLEAR, MENU, CLOCK / CALL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0+1, DISPLAY, SBASS, VOLUME+, VOL+, VOLUME, VOL, PRESET/SKIP NEXT, PRESET/SKIP PREV, INPUT+, INPUT, ABAJO, ENTER, REPEAT, BACK, SLEEP, TUNER/BAND, TV/DTV, TONE, INFO, FOLDER, EPG, SHUFFLE YES/MODE, FAV, CD PAUSE, CD STOP, / SMART, REW / TUN, VERDE, CD PLAY, AMARILLO, FWD / TUN+, AZUL, TIMER, DOCK STOP, DOCK PAUSE, DOCK PLAY, USB STOP, SIFT+IZQUIERDA, USB PLAY, DERECHA, USB PAUSE, MD/TAPE, PAUSE, STOP, PLAY, .