FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

	MEMOR		SURR –		GHT
	TOP MN		REPEA		ACK
	OPNE/CL	TV	A – B R		EEP
	PAUSI		FM MOI		DTV
5	STOP	ART	TITLE/GR		FO
0	REW		SCAN MODE		PG
CE	PLAY	V	PLAY MD		AV
	FWD		CENTER		EEN
	DVD	1	CENTER		UE
	FM/AM	2			
	TV SOUI	3			
	PTY -	4			
	PTY SEAF	5			
	PTY+	6			
	S.WFR	7			
	S.WFR	9			
	ON SCRE				
	PAGE				
	TREBLE	OL+			
	TREBLE	OL -			
	TV CH	P+			
	TV CH	P -			
	SURR –	JP			
	SURR –	WN			
	SURR –	FT			

POWER, AUDIO, MUTE, MENU, CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9/1, 06/7/8/9/, 0AUX, / SOURCE, FL DISPLAY, ZOOM, SETARRIBA, SUBTITLE, TV VOL+, VOL+, TV VOL, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SURR, SLEEP, ANGLE, TV/DTV, DIMMER, INFO, MEMORY, EPG, TOP MNEU, FAV, OPNE/CLOSE, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, DVD, FM/AM, TV SOUND, PTY, PTY SEARCH, PTY+, SWFR, SWFR+, ON SCREEN, PAGE, TREBLE+, VOL+, TREBLE, VOL, TV CH+, TV CH, SURR, REPEAT, B RPT, FM MODE, TITLE/GROARRIBA, SCAN MODE / VFP, PLAY MDOE, CENTER, CENTER+, .