FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
HOME
EXIT
1/2/3/4/5
6/7/8/9/0
CLEAR
DISPLAY
SURROUND
SETTINGS
OPTIONS
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
OK
REPEAT
A – B
INFO
POP – UP
TOP MENU

EJECT
PAUSE
STOP
REW
PLAY
FWD
DISC
RADIO
IPOD
AUX
CHANNEL+
CHANNEL -
RED/PROGRAM
GREEN/BOOKMARK
YELLOW/THUMBNAIL
BLUE/ZOOM

POWER, MUTE, HOME, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0CLEAR, DISPLAY, SURROUND, SETTINGS, OPTIONS, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, REPEAT, BACK, SLEEP, INFO, POP, EPG, TOP MENU, FAV, EJECT, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, DISC, RADIO, IPOD, AUX, CHANNEL+, CHANNEL, ROJO/PROGRAM, ROJO, VERDE/BOOKMARK, AMARILLO/THUMBNAIL, SHFIT+AMARILLO, AZUL/ZOOM, .