FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTING
1/2/3/4/5
6/7/8/9/0
+10
DISPLAY MODE
SURROUND MODE
SURROUND ON/OFF
BASS BOOST
VOLUME+
VOLUME -
TV/NEWS/INFO
DIMMER
EFFECT
|
AM
ANALOG/DIGITAL
DVD
FM
STB
TAPE
TV
VCR
SUBWOOFER -
SUBWOOFER+

REAR L+
REAR L -
REAR R+
REAR L -
BASS+
BASS -
TREBLE -
TREBLE+
PTY SEARCH
PTY -
PTY+
CENTER -
CENTER+

POWER, MUTING, MUTE, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0+1, DISPLAY MODE, SURROUND MODE, SURROUND ON/OFF, BASS BOOST, VOLUME+, VOL+, VOLUME, VOL, TV/NEWS/INFO, INFO, DIMMER, EPG, EFFECT, FAV, ANALOG/DIGITAL, DVD, STB, TAPE, VCR, SUBWOOFER, SUBWOOFER+, REAR L+, VOL+, REAR L, VOL, REAR R+, BASS+, BASS, ABAJO, TREBLE, IZQUIERDA, TREBLE+, DERECHA, PTY SEARCH, PTY, ROJO, PTY+, VERDE, CENTER, AMARILLO, CENTER+, AZUL, .