FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
TOP MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
MODE
+10 a/A
CLOCK
CALL
SETUP
DIMMER
VOLUME+
VOLUME -
SKIP NEXT/CH+
SKIP PREV/CH -
UP
DOWN
LEFT
RIGHT
ENTER
REPEAT
SLEEP
RANDOM
INFO

PROGRAM
ADD FAVORITES
STOP
REW/TUNE -
PLAY/PAUSE
FWD/TUNE+
SDB TONE
SEARCH
ANALOG IN
BLUETOOTH
CD
DIGITAL IN
POD/USB
MUSIC SERVER
TUNER
INTERNET RADIO

POWER, MUTE, TOP MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0MODE, / SOURCE, +10 a/A, CLOCK, CALL, SETARRIBA, DIMMER, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT/CH+, SKIP PREV/CH, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, SLEEP, RANDOM, TV/DTV, INFO, PROGRAM, EPG, ADD FAVORITES, FAV, STOP, / SMART, REW/TUNE, VERDE, PLAY/PAUSE, AMARILLO, FWD/TUNE+, AZUL, SDB TONE, SEARCH, ANALOG IN, AZULTOOTH, DIGITAL IN, POD/USB, MUSIC SERVER, TUNER, INTERNET RADIO, .