FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
VIDEO 1
VIDEO 2
VIDEO 3
DISC
CD
AUX
TAPE 1
TAPE 2
MASTER VOLUME+
MASTER VOLUME -
CD SKIP NEXT
CD SKIP PREV
TUNER PRESET+
TUNER PRESET -
SPEAKER A
SPEAKER B
BANK
TUNER FM
NEXT DISC
TUNER AM
CD PAUSE
CD STOP
CD PLAY/PAUSE

DECK B REV PLAY
DECK B PLAY
DECK B STOP
DECK B REW
DECK B FWD
DECK B REC/PAUSE
DECK A REV PLAY
DECK A REC/PAUSE
DECK A STOP
DECK A REW
DECK A PLAY
DECK A FWD

POWER, MUTE, VIDEO 1, VIDEO 2, VIDEO 3, DISC, AUX, TAPE 1, TAPE 2, MASTER VOLUME+, VOL+, MASTER VOLUME, VOL, CD SKIP NEXT, CD SKIP PREV, TUNER PRESET+, TUNER PRESET, ABAJO, SPEAKER A, IZQUIERDA, SPEAKER B, DERECHA, BANK, TUNER FM, TV/DTV, NEXT DISC, EPG, TUNER AM, FAV, CD PAUSE, CD STOP, / SMART, CD PLAY/PAUSE, AMARILLO, DECK B REV PLAY, VOL, DECK B PLAY, DECK B STOP, DECK B REW, DECK B FWD, DECK B REC/PAUSE, DECK A REV PLAY, BACK, DECK A REC/PAUSE, DECK A STOP, DECK A REW, VERDE, DECK A PLAY, SHFIT+AMARILLO, DECK A FWD, AZUL, .