FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
OPTION
/ ECO
AUX
BLU – RAY
DVD
GAME
INTERNET RADIO
MEDIA PLAYER
PHONO
TUNER
TV / RADIO
USB
SETUP
VOLUME+
VOLUME -
SKIP NEXT / TUNE+
SKIP PREV / TUNE -
UP
DOWN
LEFT
RIGHT
ENTER
BACK

SLEEP
CBL / SAT
BLUETOOTH
INFO
PLAY / PAUSE
QUICK SELECT 1
QUICK SELECT 2
QUICK SELECT 3
QUICK SELECT 4
CH / PAGE+
CH / PAGE -
RED / MUSIC
GREEN / MOVIE
YELLOW / PURE
BLUE / GAME

POWER, MUTE, OPTION, MENU, / ECO, EXIT, AUX, BLU, RAY, DVD, GAME, INTERNET RADIO, MEDIA PLAYER, PHONO, TUNER, 0TV / RADIO, / SOURCE, USB, SETARRIBA, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT / TUNE+, SKIP PREV / TUNE, ABAJO, IZQUIERDA, DERECHA, ENTER, BACK, SLEEP, CBL / SAT, TV/DTV, AZULTOOTH, FAV, INFO, PLAY / PAUSE, AMARILLO, QUICK SELECT 1, QUICK SELECT 2, QUICK SELECT 3, QUICK SELECT 4, CH / PAGE+, CH / PAGE, ROJO / MUSIC, ROJO, VERDE / MOVIE, VERDE, AMARILLO / PURE, AZUL / GAME, AZUL, .