FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER RECEIVER	
MUTE	
HOME / MENU	
AUDIO PARAMETER	
1/2/3/4/5	
6/7/8/9/0	
IPOD CTRL	
ACOUSTIC EQ	
DISP	
SPEAKERS	
TOOLS	
MIDNIGHT	
VOLUME+	
VOLUME -	
SKIP NEXT	
SKIP PREV	
UP	
DOWN	
LEFT	
RIGHT	
ENTER	
RETURN	
SLEEP	
ADV SURROUND	
DIMMER	

SOUND RETREIVER	
AUTO DIRECT	
PAUSE	
STOP	
REW	
PLAY	
FWD	
BD	
CD	
DVD	
GAME	
IPOD/USB	
SAT/CBL	
TUNER	
TV	
PRESET PREV	
PRESET NEXT	
TRE+	
TRE -	
CH+	
CH -	
BASS+	
BASS -	
INPUT PREV	
INPUT NEXT	

PTY	
STEREO	
PHASE	S
STANDARD	
SB CH	
CH LEVEL -	
CH SELECT	S
CH LEVEL+	

POWER RECEIVER, POWER, MUTE, HOME / MENU, MENU, AUDIO PARAMETER, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0IPOD CTRL, / SOURCE, ACOUSTIC EQ, DISP, SPEAKERS, TOOLS, MIDNIGHT, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, SLEEP, ADV SURROUND, TV/DTV, DIMMER, INFO, SOUND RETREIVER, EPG, AUTO DIRECT, FAV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, DVD, GAME, IPOD/USB, SAT/CBL, TUNER, PRESET PREV, PRESET NEXT, TRE+, VOL+, TRE, VOL, CH+, BASS+, BASS, INPUT PREV, INPUT NEXT, PTY, STEREO, PHASE, STANDARD, SB CH, CH LEVEL, CH SELECT, CH LEVEL+, .