FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
OPTION
OFF
AUX 1
AUX 2
BLUETOOTH
HDMI 1
HDMI 2
HDMI 3
NET
TV
ENHANCER
CH LEVEL
CLEAR VOICE
✿ / SETUP
ENTERTAINEMENT
VOL+
VOL -
SUB+
SUB -
UP
DOWN
LEFT
RIGHT

ENTER
⮌ / RETURN
ECO
MOVIE
..... / INFO
MUSIC
TARGET
SURROUND
STEREO
NET RADIO 1
NET RADIO 2
NET RADIO 3
SYSTEM MEMORY 1
SYSTEM MEMORY 2
SYSTEM MEMORY 3

POWER, MUTE, OPTION, MENU, OFF, EXIT, AUX 1, AUX 2, AZULTOOTH, HDMI 1, HDMI 2, HDMI 3, NET, ENHANCER, CH LEVEL, CLEAR VOICE, / SETARRIBA, ENTERTAINEMENT, VOL+, VOL, SUB+, SUB, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, ECO, SLEEP, MOVIE, TV/DTV, / INFO, INFO, MUSIC, EPG, TARGET, FAV, SURROUND, / NET TV, STEREO, / SMART, NET RADIO 1, NET RADIO 2, NET RADIO 3, SYSTEM MEMORY 1, SYSTEM MEMORY 2, SYSTEM MEMORY 3, .