FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY/ON
AUDIO
MENU
X / CANCEL
1/2/3/4/5
6/7/8/9/0
THUMBNAIL/LIST
DISPLAY
ZOOM
SET UP
SUBTITLE
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
VFP / I/P
ANGLE/ SLIDE EFFECT
ON SCREEN
TITLE/GROUP
TOP MENU
OPEN/CLOSE

AUSE
STOP
REW/SLOW -
PLAY
FWD/SLOW+
SOUND EFFECT
↻
DIMMER

STANDBY/ON, POWER, AUDIO, MUTE, MENU, X / CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0THUMBNAIL/LIST, DISPLAY, ZOOM, SET ARRIBA, SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, VFP / I/P, SLEEP, ANGLE/ SLIDE EFFECT, TV/DTV, ON SCREEN, INFO, TITLE/GROARRIBA, EPG, TOP MENU, FAV, OPEN/CLOSE, / NET TV, AUSE, STOP, / SMART, REW/SLOW, VERDE, PLAY, AMARILLO, FWD/SLOW+, AZUL, SOUND EFFECT, DIMMER, .