FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
CLEAR
1/2/3/4/5
6/7/8/9/0
MODE
+10
CLOCK
FOLDER/ALL
SETUP
RANDOM
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
REPEAT
SLEEP
DAB/RDS
INFO
PROGRAM

DIMMER
HOLD
REW/TUNE -
PLAY/PAUSE
FWD/TUNE+
ANALOG IN
BLUETOOTH
CD
OPTICAL IN 1
OPTICAL IN 2
TUNER
CHANNEL+
CHANNEL -

POWER, MUTE, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0MODE, / SOURCE, CLOCK, FOLDER/ALL, SETARRIBA, RANDOM, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, SLEEP, DAB/RDS, TV/DTV, INFO, PROGRAM, EPG, DIMMER, FAV, HOLD, / SMART, REW/TUNE, VERDE, PLAY/PAUSE, AMARILLO, FWD/TUNE+, AZUL, ANALOG IN, AZULTOOTH, OPTICAL IN 1, OPTICAL IN 2, TUNER, CHANNEL+, CHANNEL, .