FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
🔇
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
DISPLAY
ZOOM
SETUP
SUBTITLE
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN / EXIT
KEYLOCK
USB / CARD
TITLE
RANDOM
CARD SELECT
OPEN / CLOSE
PAUSE

STOP
REW
PLAY
FWD
AUTO
ANGLE
3D
SLOW/F
SLOW/R
REPEAT
REPEAT A – B
RED / DIGEST
GREEN / PROGRAM
YELLOW / BOOKMARK
BLUE / SEARCH

POWER, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DISPLAY, ZOOM, SETARRIBA, SUBTITLE, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN / EXIT, BACK, KEYLOCK, SLEEP, USB / CARD, TV/DTV, TITLE, INFO, RANDOM, EPG, CARD SELECT, FAV, OPEN / CLOSE, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUTO, ANGLE, SLOW/F, SLOW/R, REPEAT, REPEAT A, SHFIT+FAV, ROJO / DIGEST, ROJO, VERDE / PROGRAM, AMARILLO / BOOKMARK, AZUL / SEARCH, .