FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTING
DVD MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
S – AIR MODE
ONE – TOUCH PLAY
DISPLAY
PICTURE NAVI
DVD MENU
SUBTITLE / D.TUNING
VOLUME+
VOLUME -
SKIP NEXT / PRESET+
SKIP PREV / PRESET -
UP
DOWN
LEFT
RIGHT
+
/ RETURN
SLEEP
THEATER
/ DISPLAY

ANGLE
DVD TOP MENU
PAUSE
STOP
REW / TUNING -
PLAY
FWD / TUNING+
AUDIO
DYNAMIC BASS
DISC SKIP
SOUND MODE
NIGHT
FUNCTION+
FUNCTION -
REPLAY
ADVANCE

POWER, MUTING, MUTE, DVD MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, AIR MODE, / SOURCE, ONE, TOUCH PLAY, DISPLAY, PICTURE NAVI, SUBTITLE / DTUNING, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT / PRESET+, SKIP PREV / PRESET, ABAJO, IZQUIERDA, DERECHA, / RETURN, BACK, SLEEP, THEATER, TV/DTV, / DISPLAY, INFO, ANGLE, EPG, DVD TOP MENU, FAV, PAUSE, STOP, / SMART, REW / TUNING, VERDE, PLAY, AMARILLO, FWD / TUNING+, AZUL, AUDIO, DYNAMIC BASS, DISC SKIP, SOUND MODE, NIGHT, FUNCTION+, FUNCTION, REPLAY, ADVANCE, .