FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTING
MENU / PLAY LIST
CANCEL
1/2/3/4/5
6/7/8/9/0
FUNCTIONS
-/-- / > = 10
FL DISPLAY / SLEEP
C. FOCUS
SW. LEVEL
PL / S. SRD
VOLUME+
VOLUME -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN / SETUP
ONE TOUCH PLAY
TEST
CH. SELECT / PLAY MODE

EQ / SRD ENH.
DIR. NAV. / TOP MENU
PAUSE
STOP
REW
PLAY
FWD
DVD
EXT IN
FM

POWER, MUTING, MUTE, MENU / PLAY LIST, MENU, CANCEL, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0FUNCTIONS, SOURCE, / x, FL DISPLAY / SLEEP, C FOCUS, SW LEVEL, PL / S SRD, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT, SKIP, PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN / SETARRIBA, BACK, ONE TOUCH PLAY, SLEEP, TEST, TV/DTV, CH SELECT / PLAY MODE, INFO, EQ / SRD ENH, EPG, DIR NAV / TOP MENU, FAV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, DVD, EXT IN, .