FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY/ON
MUTING
MENU
SEARCH
1/2/3/4/5
6/7/8/9/0
10+
DISPLAY
ZOOM
SETUP
SUBTITLE
VOL+
VOL -
SKIP/PRESET NEXT
SKIP/PRESET PREV
UP / ANGLE
DOWN / SLOW
LEFT
RIGHT
ENTER
REPEAT
TIMER/SLEEP
CLOCK
DIMMER
MEMORY/PROG

REPEAT A – B
STOP / FM MODE
REW / TUNING+
PLAY/PAUSE
FWD / TUNING -
AUDIO
DVD
IPOD
LIME
FM
TITLE
S.BASS
TONE

STANDBY/ON, POWER, MUTING, MUTE, MENU, SEARCH, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 010+, DISPLAY, ZOOM, SETARRIBA, SUBTITLE, VOL+, VOL, SKIP/PRESET NEXT, SKIP/PRESET PREV, ARRIBA / ANGLE, ABAJO / SLOW, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, TIMER/SLEEP, SLEEP, CLOCK, TV/DTV, DIMMER, INFO, MEMORY/PROG, EPG, REPEAT A, FAV, STOP / FM MODE, / SMART, REW / TUNING+, VERDE, PLAY/PAUSE, AMARILLO, FWD / TUNING, AZUL, AUDIO, DVD, IPOD, LIME, TITLE, SBASS, TONE, .