FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY/ON
/ AUDIO
HOME MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
HOME MENU GALLERY
DISPLAY
PHOTO ZOOM
/ ANGLE
/ SUBTITLE
OUTPUT RESOLUTION+
OUTPUT RESOLUTION -
SKIP NEXT
SKIP PREV
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
PLAY MODE
POPUP MENU
FL DIMMER
VIDEO ADJUST

DISC NAV./TOP MENU
OPEN/CLOSE
PAUSE
STOP
REW
PLAY
FWD
◀II
II▶
RED
GREEN
YELLOW
BLUE

STANDBY/ON, POWER, / AUDIO, MUTE, HOME MENU, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0HOME MENU GALLERY, DISPLAY, PHOTO ZOOM, / ANGLE, / SUBTITLE, OUTPUT RESOLUTION+, VOL+, OUTPUT RESOLUTION, VOL, SKIP NEXT, SKIP PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, PLAY MODE, SLEEP, POPARRIBA MENU, TV/DTV, FL DIMMER, INFO, VIDEO ADJUST, EPG, DISC NAV/TOP MENU, FAV, OPEN/CLOSE, / NET TV, PAUSE, STOP, / SMART, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, ROJO, .