FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

ON/STANDBY
MUTE
MENU
CLEAR
1/2/3/4/5
6/7/8/9/0
MODE
+10
DISPLAY
CLOCK
RANDOM
SEARCH
VOLUME+
VOLUME -
SKIP NEXT/TUN+
SKIP PREV/TUN -
UP
DOWN
LEFT
RIGHT
ENTER
REPEAT
SLEEP
HOME
DIMMER

PROGRAM
SDB TONE
STOP
REW
PLAY/PAUSE
FWD
AUX
CD
FAVORITE
IPOD
MUSIC SERVER
ONLINE MUSIC
INTERNET RADIO
TUNER
USB
CHANNEL+
CHANNEL -

ON/STANDBY, POWER, MUTE, MENU, CLEAR, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0MODE, / SOURCE, DISPLAY, CLOCK, RANDOM, SEARCH, VOLUME+, VOL+, VOLUME, VOL, SKIP NEXT/TUN+, SKIP PREV/TUN, ABAJO, IZQUIERDA, DERECHA, ENTER, REPEAT, BACK, SLEEP, HOME, TV/DTV, DIMMER, INFO, PROGRAM, EPG, SDB TONE, FAV, STOP, / SMART, REW, VERDE, PLAY/PAUSE, AMARILLO, FWD, AZUL, AUX, FAVORITE, IPOD, MUSIC SERVER, ONLINE MUSIC, INTERNET RADIO, TUNER, USB, CHANNEL+, CHANNEL, .