FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY/ON
MUTING
MENU
1/2/3/4/5
6/7/8/9/0-10
SELECT/FM MODE
10+
OSD
ZOOM
SETUP
SUBTITLE
VOL+
VOL -
SKIP NEXT/TUNING+
SKIP PREV/TUNING -
UP
DOWN
LEFT
RIGHT
SLEEP/TIMER
DIMMER
INFO/RDS/REPEAT
PROG/MEM
A – B

EJECT
STOP/SCAN
REW/PRESET-
PLAY/PAUSE
FWD/PRESET+
AUDIO
AUX
DISC
IPOD/USB
TUNER
CLOCK
TIME
ANGLE
SLOW
LOUDNESS
TITLE

STANDBY/ON, POWER, MUTING, MUTE, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SELECT/FM MODE, / SOURCE, 10+, OSD, ZOOM, SETARRIBA, SUBTITLE, VOL+, VOL, SKIP NEXT/TUNING+, SKIP PREV/TUNING, ABAJO, IZQUIERDA, DERECHA, SLEEP/TIMER, SLEEP, DIMMER, TV/DTV, INFO/RDS/REPEAT, INFO, PROG/MEM, EPG, FAV, EJECT, / NET TV, STOP/SCAN, / SMART, REW/PRESET, VERDE, PLAY/PAUSE, AMARILLO, FWD/PRESET+, AZUL, AUDIO, AUX, DISC, IPOD/USB, TUNER, CLOCK, TIME, ANGLE, SLOW, LOUDNESS, TITLE, .