FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
S SUB MENU
TIME SLIP
1/2/3/4/5
6/7/8/9/0
INPUT SELECT
RESET
B / DISPLAY
C / CHAPTER CREATE
STATUS
DIRECT NAVIGATOR
SKIP NEXT CHAP.
SKIP PREV. CHAP.
CH / PAGE +
CH / PAGE -
UP
DOWN
LEFT
RIGHT
OK
RETURN
SHOWVIEW
DRIVE SELECT
PROG CHECK
PAUSE

STOP
REC
REW
PLAY
FWD
A / AUDIO
MANUAL SKIP
FUNCTIONS
REC MODE
DIRECT TV REC
EXT LINK

POWER, S SUB MENU, MENU, TIME SLIP, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT SELECT, / AV, RESET, B / DISPLAY, C /, CHAPTER CREATE, STATUS, DIRECT NAVIGATOR, SKIP NEXT, CHAP, VOL+, SKIP PREV CHAP, VOL, CH / PAGE, CH / PAGE, ABAJO, IZQUIERDA, DERECHA, RETURN, BACK, SHOWVIEW, INFO, DRIVE SELECT, EPG, PROG CHECK, FAV, PAUSE, STOP, REC, ROJO, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, A / AUDIO, MUTE, MANUAL, SKIP, FUNCTIONS, REC MODE, DIRECT TV REC, EXT LINK, .