FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
/ MENU
EXIT
1/2/3/4/5
6/7/8/9/0
REMAIN
DIMMER
ZOOM
P. BASS
SUBTITLE
VOLUME+
VOLUME-
TUNING / CH+
TUNING / CH-
UP
DOWN
LEFT
RIGHT
/ ENTER
/ RETURN
SLEEP
LOGO
INFO
TUNER MEMORY

SOUND
EJECT
PAUSE
STOP
REW
PLAY
FWD
AUDIO
CANCEL
AUX
DVD
PORT
TUNER
SKIP NEXT
SKIP PREV.
REPEAT
STEP
SLOW / MO/ST

POWER, MUTE, / MENU, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0REMAIN, DIMMER, ZOOM, P BASS, SUBTITLE, VOLUME+, VOL+, VOLUME, VOL, TUNING / CH+, TUNING, / CH, ABAJO, IZQUIERDA, DERECHA, / ENTER, RETURN, BACK, SLEEP, LOGO, TV/DTV, INFO, TUNER MEMORY, EPG, SOUND, FAV, EJECT, PAUSE, STOP, REW, VERDE, PLAY, AMARILLO, FWD, AZUL, AUDIO, CANCEL, AUX, DVD, PORT, TUNER, SKIP NEXT, SKIP PREV, REPEAT, STEP, SLOW, / MO/ST, .