FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

⏻
MUTE
MENU
X / EXIT
1/2/3/4/5
6/7/8/9/0
INPUT AV
/ LAST VIEW
/ SURROUND
/ STTL
TEXT
VOL+
VOL -
CH+
CH -
UP
DOWN
LEFT
RIGHT
OK
BACK / RETURN
/ OFF TIMER
INPUT TV
i
GUIDE

/ HOLD
RED
GREEN
YELLOW
BLUE
AUDIO
OPTION
USB PLAY/BACK
/ ASPECT
N
/ INDEX
DV
⏻
PROGRAMME+
PROGRAMME -
PAUSE / STEP
STOP
REC
REW / SKIP PREV
PLAY
FWD / SKIP NEXT

POWER, MUTE, MENU, X / EXIT, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT AV, / SOURCE, / LAST VIEW, / SURROUND, / STTL, TEXT, VOL+, VOL, CH+, ABAJO, IZQUIERDA, DERECHA, BACK / RETURN, BACK, / OFF TIMER, SLEEP, INPUT TV, TV/DTV, INFO, GUIDE, EPG, / HOLD, / SMART, ROJO, VERDE, AMARILLO, AZUL, AUDIO, OPTION, USB PLAY/BACK, / ASPECT, INDEX, DVD, PROGRAMME+, PROGRAMME, PAUSE / STEP, STOP, REC, REW / SKIP, PREV, PLAY, FWD / SKIP NEXT, .