FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

POWER
MUTE
MENU
EXIT
1/2/3/4/5
6/7/8/9/0
SOURCE
JUMP
P. MODE
SUBTITLE
TEXT
VOL+
VOL -
P +/-
UP
DOWN
LEFT
RIGHT
OK
GO TO
SLEEP
DTV / RADIO
INFO
GUIDE

FAV. CH
RED
GREEN
YELLOW
BLUE
I/II AUDIO
DVD MENU
S. MODE
USB / SD
PVR LIST
P. SIZE
ZOOM
SKIP NEXT/PREV
REPEAT
TIME SHIFT
D. SETUP
EJECT
STOP
REC
REW
PLAY
FWD

POWER, MUTE, MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0SOURCE, / SOURCE, JUMP, MODE, SUBTITLE, TEXT, VOL+, VOL, ABAJO, IZQUIERDA, DERECHA, GO TO, BACK, SLEEP, DTV / RADIO, TV/DTV, INFO, GUIDE, EPG, FAV CH, FAV, / SMART, ROJO, VERDE, AMARILLO, AZUL, I/II, AUDIO, DVD MENU, S MODE, USB / SD, PVR LIST, P SIZE, ZOOM, SKIP, NEXT/PREV, P +/, REPEAT, TIME SHIFT, D SETARRIBA, EJECT, STOP, REC, REW, PLAY, FWD, .