FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

I/⏻
MUTING
MENU
TOP MENU
1/2/3/4/5
6/7/8/9/0
INPUT SELECT
-/--
DISPLAY
ZOOM
ANGLE
SUBTITLE
SHUTTLE NEXT
SHUTTLE PREV
UP
DOWN
LEFT
RIGHT
ENTER
🎧 / RETURN
TIMER
TV / VIDEO
INDEX
SQPB
SURROUND

EJECT
PAUSE
STOP
REC
SCAN/SLOW REW
PLAY
SCAN/SLOW FWD
AUDIO
SET UP
CLEAR
SELECT - DVD
SELECT - VIDEO
SP / LP
PICTURE NAVI.
PROG./TRACKING+
PROG./TRACKING -
REPEAT
PROGRAM
STEP

POWER, MUTING, MUTE, MENU, TOP MENU, EXIT, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT, SELECT, / SOURCE, DISPLAY, ZOOM, ANGLE, SUBTITLE, SHUTTLE NEXT, SHUTTLE PREV, ABAJO, IZQUIERDA, DERECHA, ENTER, / RETURN, BACK, TIMER, SLEEP, TV / VIDEO, TV/DTV, INDEX, INFO, SQPB, EPG, SURROUND, FAV, EJECT, / NET TV, PAUSE, STOP, / SMART, REC, ROJO, SCAN/SLOW, REW, VERDE, PLAY, AMARILLO, SCAN/SLOW FWD, AZUL, AUDIO, SET ARRIBA, CLEAR, SELECT, DVD, VIDEO, SP / LP, PICTURE NAVI, PROG/TRACKING, PROG/TRACKING, REPEAT, PROGRAM, STEP, .