FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

I/⏻
AUDIO
MENU
1/2/3/4/5
6/7/8/9/0
INPUT SELECT
DISPLAY
SYSTEM MENU
OPTIONS
SKIP NEXT
SKIP PREV
PROG+
PROG -
UP
DOWN
LEFT
RIGHT
ENTER
RETURN
TV / DVD
TITLE LIST
TOP MENU
EJECT
PAUSE
STOP

REC
REW / SLOW REW
PLAY
FWD / SLOW FWD
HDD
DVD
CHAPT. MARK – MARK
CHAPT. MARK – ERASE
TIMER
TIMER LIST
TIME / TEXT
SUBTITLE
←•
•→
REC MODE
REC STOP
SYNCHRO REC
T
I/⏻
→
VOL+
VOL -
PROG+
PROG -

POWER, AUDIO, MUTE, MENU, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0INPUT SELECT, / SOURCE, DISPLAY, SYSTEM MENU, OPTIONS, SKIP NEXT, VOL+, SKIP, PREV, VOL, PROG+, PROG, ABAJO, IZQUIERDA, DERECHA, ENTER, RETURN, BACK, TV / DVD, TV/DTV, TITLE LIST, INFO, TOP, EPG, EJECT, / NET TV, PAUSE, STOP, / SMART, REC, ROJO, REW / SLOW REW, VERDE, PLAY, AMARILLO, FWD / SLOW FWD, AZUL, HDD, DVD, CHAPT MARK, MARK, ERASE, TIMER, TIMER LIST, TIME / TEXT, SUBTITLE, REC MODE, FAV, REC STOP, SYNCHRO REC, SHIFT, .