FUNCIONES DEL MANDO PROGRAMADO:

En este documento puede visualizar las funciones que se van a programar en el mando.
El mapa de botones completo se lo facilitaremos impreso en papel junto con la compra del producto.
Revise que localiza todas las funciones que necesita antes de realizar la compra.

STANDBY/ON
MUTE
1/2/3/4/5
6/7/8/9/0
DIRECT
LEVEL CH. SELECT
CINEMA FILTER
ALL CH. STEREO
AUDIO ADJUST
AUDIO SEL.
VOL+
VOL -
PRESET NEXT
PRESET PREV
UP
DOWN
LEFT
RIGHT
OK
SLEEP
DIMMER
LEVEL TEST
STEREO
SURROUND
POWER OFF

DSP
VIDEO 1
VIDEO 2
VIDEO 3
CD
DVD
TAPE
TUNER
STANDBY ON
SPEAKER A
SPEAKER B
LEVEL DOWN
LEVEL UP
LATE NIGHT

STANDBY/ON, POWER, MUTE, 1/2/3/4/5, 6/7/8/9/, 06/7/8/9/, 0DIRECT, SOURCE, LEVEL CH SELECT, CINEMA FILTER, ALL CH, STEREO, AUDIO ADJUST, AUDIO SEL, VOL+, VOL, PRESET NEXT, PRESET, PREV, ABAJO, IZQUIERDA, DERECHA, SLEEP, DIMMER, INFO, LEVEL TEST, ROJO, VERDE, SURROUND, AMARILLO, POWER OFF, DSP, VIDEO 1, VIDEO 2, VIDEO 3, DVD, TAPE, TUNER, STANDBY, 0SPEAKER A, SPEAKER B, VOL+, LEVEL ABAJO, LEVEL ARRIBA, LATE NIGHT, .